LS5050 INSTALLATION GUIDE (RECESSED)


⚠ **WARNING** **Failure to comply with the following installation instructions may result in death or serious injury.**


- This product must be installed and serviced by a qualified electrician.
- Separate the power supply wiring (110V) and dimming/control wiring
- Disconnect power before installing to avoid electrical shock
- Do not exceed fixture specified voltage
- Do not expose IP33-rated lighting fixtures or LED strip to moisture generated from steam, water drips, as well as condensation residues, as it will cause damage to the light components causing a possible short circuit.
- Power cable should not support the weight of the fixture and stay loose
- Do not use fixture, parts or connectors which are damaged

⚠ **CAUTION**


- Should a production received with missing or damaged parts, please contact Joyolight at 1-877-849-1942.
- Should a fixture not work properly, please turn fixture off and contact Joyolight technical support for immediate assistance.
- Handle the fixture with care throughout the installation in case of damaging the fixture.
- Always wear clean latex or cotton gloves to avoid spots or fingerprint marks on the fixture.
- Unauthorized field repairs will void warranty

STEP 1:





- Use tapping screw to fix air brackets on the profile




JOYOLIGHT GROUP INC.

#12, 5200 Dixie road
Mississauga, ON, L4W 1E4


www.joyolight.ca
info@joyolight.com
1-877-849-1942 (US)
647-496-8107 (CA)

STEP 2:



- Cut suitable slot on the ceiling
- To cover the air bracket:
  1. Cover the fixture and lens with masking tape
  2. Plaster over the air bracket and wall/ceiling
  3. Remove the masking tape

STEP 3:



- Complete installation

JOYOLIGHT GROUP INC.

#12, 5200 Dixie road
Mississauga, ON, L4W 1E4

www.joyolight.ca
info@joyolight.com
1-877-849-1942 (US)
647-496-8107 (CA)